

Hammar Deckvest Seasonal Service Schedule

spinlock
deckware series

It is important to look after your Hammar Deckvest Lifejacket Harness, particularly before the new season and after the winter when it is often not used. Care at this time will extend the life of the product and ensure it is ready for another season.

As part of our commitment to Through Life Support for the Deckvest registration of your Deckvest is vitally important to record your ownership of this lifesaving product. By trusting us with your contact data you will greatly assist us in reaching you if we have important product information to pass on to you in the future. More important, your comments, with those of other Registered Owners, will help us to monitor the durability and reliability of your Deckvest throughout its life and continuously refine its specification for Deckvest owners in the future.

1: Clean

Remove the hammar firing head and cylinder from inside the bladder. Clean the Lifejacket Harness to remove any general dirt or mould which may have accumulated. Any salt left during the winter period will have absorbed moisture from the air making the product damp which in turn could have lead to mould.

2: Inflate

Use the oral inflation tube to inflate the bladder and leave for 24 hours. The Lifejacket should still retain most of it's air after this period. If it has gone down completely there is a leak and the bladder should be replaced.

3: Dry

Ensure the whole product is dry after being cleaned, importantly store it in a warm dry place prior to use.

4: Inspect

Before repacking give the whole product a good inspection, you are looking for any signs of wear, loose threads, tears or general damage. Check for expiry dates and green markings on the firing head and cylinder and ensure that the two halves of the Hammar firing head form a good seal around the bladder. Check that the light is still in working order. If in any doubt have the Deckvest serviced by an authorised service centre. Instructions booklets and videos can be found at www.spinlock.co.uk on the Deckvest Product Pages.

5: Re-pack

Re-Pack the bladder back into the lifejacket cover as per the instructions. Instructions booklets and videos can also be found at www.spinlock.co.uk on the Deckvest Product Pages. (Videos also on YouTube).



HAMMAR